



#### INSTALLATION INSTRUCTIONS

THE FOLLOWING SHOULD BE PREPARED AT THE TIME OF CONSTRUCTION.

**FREE ZONE ON THE WALL BEHIND THE APPARATUS.**  
IN MARKED FREE ZONE THERE SHOULD BE NO OBSTRUCTIONS THAT MAY AFFECT THE INSTALLATION, INCLUDING WIRING, RADIATORS OR VENTILATION DUCTS.

**WALL TO BE VERTICAL WITHOUT PARAPET OR SIMILAR.**

**FOR TIMBER WALLS:**  
MARKINGS SHOW WHERE TIMBER REINFORCEMENT WITH A WIDTH OF 90 MM AND HEIGHT OF 145 MM SHOULD BE INSTALLED. ALL REINFORCEMENTS TO BE DIRECTLY BEHIND WALL SURFACE TO PROVIDE TIGHTENING OF EQUIPMENT. ALL REINFORCEMENTS MUST BE SECURELY FIXED TO THE WALL. LOAD IS CIRCA 200 KG PER METRE/ ATTACHMENT RULE. ALL WALLS ARE VIEWED FROM INSIDE THE HALL. PLASTER MUST NOT OUTERMOST LAYER.

**FREE ZONE IN THE FLOOR:**  
IN MARKED ZONE FLOOR ANCHORS FOR THE APPARATUS WILL BE INSTALLED IN THE FLOOR SURFACE. THE FREE MOUNTING DEPTH IN THESE AREAS SHOULD BE MINIMUM 100 MM.

**FASTENINGS NOT INCLUDED.**

Equipment Schedule			
Item:	Product Code:	Qty:	Notes:
Single Pivoting Module, hinged on the left	307010	1	To be selected from frame options shown on Product Data Sheet
Single Pivoting Module, hinged on the right	307014	1	To be selected from frame options shown on Product Data Sheet
Connection Beam	307015	1	
Climbing Net	307016	1	
Timber Plank	300450	2	

Rev:	Description:	Date:	By:

Drawing Name:  
**CLM-BORGEN-DBL**  
**Two Pivoting Modules,**  
**Complete with Linking Beam**  
**and Climbing Net**

Drawn By: MS  
Date: 09-02-12  
Checked By: CLK  
Scale: 1/75 @ A3



**Please note:**  
This drawing is intended as a guide only. Sport Alpha UK should be consulted to approve any fixing provisions prior to installation. Please note that non-standard fixings which require specialised fixing or additional drilling, etc. may incur additional charges. If in doubt, contact us.

**Sport Alpha UK Ltd**  
Unit 5, Burnbank Business Units  
Souter Head Road  
Aldens Industrial Estate  
Aberdeen AB12 3LF

T: 01224 899599  
E: info@sportalphauk.com  
W: www.sportalphauk.com