

INSTALLATION INSTRUCTIONS
THE FOLLOWING INSTRUCTIONS MUST BE PREPARED PRIOR TO INSTALLATION

ZONE ON WALL BEHIND THE BASKETBALL GOAL
IN THIS MARKED FREE ZONE THERE MUST BE NO OBSTRUCTIONS THAT MAY AFFECT
IXING OF THE GOAL TO THE WALL (FOR EXAMPLE WIRING, RADIATOR PIPES OR

THICKNESS OF 98MM AND A WIDTH OF 148MM ARE NEEDED. ALL REINFORCEMENTS MUST BE LOCATED DIRECTLY BEHIND THE WALL SURFACE TO GIVE A RIGID FASTENING WHEN MOUNTING THE BASKETBALL GOAL ONTO THE WALL SURFACE. ALL REINFORCEMENTS MUST BE FIRMLY ANCHORED TO THE WALL. ALL WALLS ARE VIEWED FROM THE INSIDE OF THE ROOM. PLASTER BOARD MUST NOT BE THE OUTER LAYER. THE WALL MUST BE VERTICAL WITHOUT ANY OBSTRUCTIONS. FOR TIMBER STUD WALLS (OR WHERE THE WALL IS OF INSUFFICIENT STRENGTH TO SUPPORT THE GOAL), THE MARKINGS SHOW WHERE TIMBER REINFORCEMENTS WITH A

THE APPROXIMATE WEIGHT OF A COMPLETE GOAL IS 34KG.

PLEASE NOTE THAT 320KG SHOULD BE ADDED TO THE OUTER EDGE OF THE RING FOR LIVE LOAD.

WHERE REINFORCEMENTS / SECONDARY SUPPORTS ARE REQUIRED, THESE ARE TO BE PROVIDED BY THE CLIENT.

