


INSTALLATION INSTRUCTIONS

THE FOLLOWING SHOULD BE PREPARED AT THE TIME OF CONSTRUCTION.

 **FREE ZONE ON THE WALL BEHIND THE APPARATUS.**
IN MARKED FREE ZONE THERE SHOULD BE NO OBSTRUCTIONS THAT MAY AFFECT THE INSTALLATION, INCLUDING WIRING, RADIATORS OR VENTILATION DUCTS.

 **WALL TO BE VERTICAL WITHOUT PARAPET OR SIMILAR.**

 **FOR TIMBER WALLS:**
MARKINGS SHOW WHERE TIMBER REINFORCEMENT WITH A WIDTH OF 90 MM AND HEIGHT OF 145 MM SHOULD BE INSTALLED. ALL REINFORCEMENTS TO BE DIRECTLY BEHIND WALL SURFACE TO PROVIDE DUMB TIGHTENING OF EQUIPMENT. ALL REINFORCEMENTS MUST BE SECURELY FIXED TO THE WALL. LOAD IS CIRCA 200 KG PER METRE/ ATTACHMENT RULE. ALL WALLS ARE VIEWED FROM INSIDE THE HALL. PLASTER MUST NOT OUTERMOST LAYER.

 **FREE ZONE IN THE FLOOR:**
IN MARKED ZONE FLOOR ANCHORS FOR THE APPARATUS WILL BE INSTALLED IN THE FLOOR SURFACE. THE FREE MOUNTING DEPTH IN THESE AREAS SHOULD BE MINIMUM 100 MM.
FASTENINGS NOT INCLUDED.

Equipment Schedule			
Item:	Product Code:	Qty:	Notes:
Borgen BAS Climbing Frame, hinged on the left	307010	1	Consists of Wall Bars, Climbing Wall and Climbing Wall Modules
Climbing Ladder Module, hinged on the left	307014	1	
Connector Beam	307015	1	
Climbing Net	307016	1	
Standard Blind	300450	2	
Standard Wall Bar Section, 765mm wide x 2475mm high	300471	1	

Rev:	Description:	Date:	By:

Drawing Name:
**CLM-BORGEN-ALL-WBS
Borgen BAS Climbing System,
Plus Additional Frame, Scramble
Net and Wall Bar Section**

Drawn By: MS
Date: 09-02-12
Checked By: CLK
Scale: 1/75 @ A3



Please note:
This drawing is intended as a guide only. Sport Alpha UK should be consulted to approve any fixing provisions prior to installation. Please note that non-standard fixings which require specialised fixing or additional drilling, etc. may incur additional charges. If in doubt, contact us.

Sport Alpha UK Ltd
Unit 5, Burnbank Business Units
Souter Head Road
Aldens Industrial Estate
Aberdeen AB12 3LF

T: 01224 899559
E: info@sportalphauk.com
W: www.sportalphauk.com