


INSTALLATION INSTRUCTIONS

THE FOLLOWING SHOULD BE PREPARED AT THE TIME OF CONSTRUCTION.

 **FREE ZONE ON THE WALL BEHIND THE APPARATUS.**
 IN MARKED FREE ZONE THERE SHOULD BE NO OBSTRUCTIONS THAT MAY AFFECT THE INSTALLATION, INCLUDING WIRING, RADIATORS OR VENTILATION DUCTS

WALL TO BE VERTICAL WITHOUT PARAPET OR SIMILAR.

 **FOR TIMBER WALLS:**
 MARKINGS SHOW WHERE TIMBER REINFORCEMENT WITH A WIDTH OF 90 MM AND HEIGHT OF 145 MM SHOULD BE INSTALLED. ALL REINFORCEMENTS TO BE DIRECTLY BEHIND WALL SURFACE TO PROVIDE DUMB TIGHTENING OF EQUIPMENT. ALL REINFORCEMENTS MUST BE SECURELY FIXED TO THE WALL. LOAD IS CIRCA 200 KG PER METRE/ ATTACHMENT RULE. ALL WALLS ARE VIEWED FROM INSIDE THE HALL. PLASTER MUST NOT OUTERMOST LAYER.

 **FREE ZONE IN THE FLOOR:**
 IN MARKED ZONE FLOOR ANCHORS FOR THE APPARATUS WILL BE INSTALLED IN THE FLOOR SURFACE. THE FREE MOUNTING DEPTH IN THESE AREAS SHOULD BE MINIMUM 100 MM.
FASTENINGS NOT INCLUDED.

Equipment Schedule			
Item:	Product Code:	Qty:	Notes:
Borgen BAS Climbing Frame, hinged on the left	307010	1	Consists of Wall Bars, Climbing Wall and Climbing Net Modules
Timber Plank	300450	1	
10-Pack Climbing Hand Holds	307040/12	1	Choose from Beginner, Medium or Advanced
10-Pack Ball Seat for Climbing Holds	307046	1	

Rev:	Description:	Date:	By:
1	Title block updated	06-01-17	MNS

Drawing Name:
CLM-BORGEN-BAS
 Borgen BAS Climbing System,
 Three Panel Climbing Frame

Drawn By: MNS
 Date: 09-02-12
 Checked By: CLK
 Scale: 1/75 @ A3



Please note:
 This drawing is intended as a guide only. Sport Alpha UK should be consulted to approve any fixing provisions prior to installation. Please note that non-standard fixings which require specialised fixing or additional drilling, etc. may incur additional charges. If in doubt, contact us.

Sport Alpha UK Ltd
 Unit 5, Burnbank Business Units
 Souther Head Road
 Airdens Industrial Estate
 Airdren AB12 3LF

T: 01224 899599
 E: info@sportalphauk.com
 W: www.sportalphauk.com